



QUICK START GUIDE

300Mbps Wireless Router



www.wavlink.com/en_us/WL-WN529K2
Scan the QR code or load the link for Quick Start Guide downloading



WAVLINK (@WavlinkOfficial)
WAVLINK SUPPORT (@WavlinkTechSupport)

WL-WN529K2

Safety Instructions

Always read the safety instructions carefully. Keep this Quick Start Guide for future reference. Keep this equipment away from humidity. If any of the following situation arises, get the equipment checked by a service technician:

- The equipment has been exposed to moisture.
- The equipment has been dropped and damaged.
- The equipment has obvious sign of breakage.
- The equipment has not been working well or you cannot get it work according to Quick Start Guide.

Copyright Statement

No part of this publication may be reproduced in any form by any means without the prior written permission. Other trademarks or brand names mentioned herein are trademarks or registered trademarks of their respective companies.

Disclaimer

Information in this document is subject to change without notice. The manufacturer does not make any representations or warranties (implied or otherwise) regarding the accuracy and completeness of this document and shall in no event be liable for any loss of profit or any commercial damage, including but not limited to special, incidental, consequential, or other damage.


WEEE Directive & Product Disposal



At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

01

Overview



- ① Smart antenna
- ② WPS/Reset button
- ③ 1 x 10/100Mbps WAN port
- ④ 4 x 10/100Mbps LAN port

WPS: press and hold WPS button for **1 to 2** seconds.

Reset: press and hold reset button for **6** seconds.

LED Indicator

LED indicator	Status
Solid blue	The Internet is connected.
Flashing blue	The router is trying to establish WPS connection.
Flashing red	The Internet is disconnected.

02


Basic Info

Default IP: 192.168.10.1
Login URL: <http://wifi.wavlink.com>
Default Password: **admin**
SSID: **WAVLINK-N**
Official Website: www.wavlink.com
Technical Support: support@wavlink.com

Connection


1. Connection via cable

Connect Ethernet cable to your PC/laptop and device's LAN port, then you can start configuring.




2. Wireless Connection

Turn on your Wi-Fi to search SSID "WAVLINK-N" and connect to it, then you can start configuring.




For Windows users



For Mac users

03

3. Connect on your phone
- 1) Switch to the Wi-Fi connection page on your phone.
- 2) Find the SSID "WAVLINK-N", then connect to it.



Configuration


1. Launch a browser from your laptop/PC or smart phone and enter wifi.wavlink.com or 192.168.10.1 in the address field. The default password is **admin** (all lowercase).

Note: If the login window doesn't show up, please check [FAQ> Q1](#).

04




2. Select **Router** mode.



Note: Other modes are for advanced users when necessary.

05

3. Now you can set up your WAN Type(PPPoE, Static IP and Dynamic IP), then select **Security Type** and create a **Wi-Fi Password** for security.



Which WAN Type am I supposed to choose?

If you use DSL line and you are only provided an account name and a password by your ISP, choose **PPPoE**. If you use cable TV or fiber cable, choose **DHCP(Dynamic IP)**. If you are provided information such as IP address, Subnet Mask and Default Gateway, choose **Static IP**.


4. Click **Apply** and wait patiently for the configuration process to complete.

06

Change login Password

If you need to reset the login password, please follow steps below:

1. Log in to wifi.wavlink.com or 192.168.10.1.
2. Click "**Setup**" --> "**Login Password**".
3. Enter the old and new password (case-sensitive) and click on "**Apply**" button to confirm.




07

Wi-Fi Setup

If you need to manage your WiFi setup, you can check the following steps for reference:

1. Click "**Wi-Fi**" > "**Wi-Fi Setup**".
2. You can set "**Security Type**" as "**OPEN**" but we strongly recommend that you use "**WPA2-PSK**" and set a new WiFi password for network security.




08

Firmware Upgrade

If you need to update firmware, please follow steps below:

1. Download the latest firmware file on Wavlink website.
2. Extract the firmware from the downloaded file.
3. Log in to 192.168.10.1 or wifi.wavlink.com, then choose "**Setup**" and select "**Upgrade Firmware**".



4. Click on **Select file** to locate the extracted firmware file.
5. Click on **Apply**, and wait for the firmware upgrade process to complete.

What is firmware upgrade and why do I need it?

Firmware fixes bugs for your device, contains new features, and improves the experience of using the product. For your device update and security, please ask us for help. Wrong upgrade may damage your device and void the product warranty.

For more details, please visit our website www.wavlink.com
Our Technical Support: support@wavlink.com

09

FAQ

Q1. Why doesn't the login page appear after entering <http://wifi.wavlink.com> ?

- Make sure your PC is set to obtain IP address automatically.
- Please make sure you entered the correct website.
- Reboot your device and try again.

Q2. What can I do if I can not access the Internet?

- Make sure your Internet works normally, please contact your **ISP**(Internet Service Provider) if it doesn't.
- Initiate your browser, enter 192.168.10.1 or wifi.wavlink.com, then set up the following quick start guide.
- Reboot your device and try again.

Q3. What should I do if I can't have access to 192.168.10.1 or wifi.wavlink.com on my android phone?

- We suggest you turn off your 4G signal first before you set up the network, then turn it on when the configuration is done.

Q4. What can I do if I forget my administration management password?

- Please reset the device, the default password is [admin](#) .

Q5. How do I find the best location for mesh devices?

- Please put your router in a relatively open space to avoid obstacles such as metal objects, reinforced concrete walls and so on.

Please visit https://www.wavlink.com/en_us/faq.html for more details.

10

GNU GENERAL PUBLIC LICENSE NOTICE

This product includes software codes developed by third parties. These software codes are subject to either the GNU General Public License (GPL), Version 2, June 1991 or the GNU Lesser General Public License (LGPL), Version 2.1, February 1999. You can copy, distribute, and/or modify in accordance with the terms and conditions of GPL or LGPL.

The source code should be complete, if you want us to provide any additional source code files under GNU General Public License (GPL), please contact us in these matters. We are committed to meeting the requirements of the GNU General Public License (GPL). You are welcome to contact our local office to get the corresponding software and licenses. Please inform us of your contact details (full address) and the product code. We will send you a software package with the software and license for free.

The respective programs are distributed WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

Please refer to the GNU General Public License website for further information.

<http://www.gnu.org/licenses/old-licenses/lgpl-2.0.html>

<http://www.gnu.org/licenses/gpl.html>

WEEE Directive & Product Disposal



At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

11