WAVLINK

see the world

QUICK START GUIDE

AX1800M USB3.0 Wireless Adapter

WAVLINK (@WavlinkOfficial)
WAVLINK SUPPORT (@WavlinkTechSupport)

Vitesse Pro-B

Safety Instructions

Keep this quick start guide for future reference.
Keep this equipment away from humidity.
If any of the following situation arises, get the device checked by a service technician.

- The equipment has been exposed to moisture.
- The equipment has been dropped and damaged.
- The equipment has obvious sign of breakage.
- The equipment has not been working well or you cannot get it work according to QUICK START GUIDE.

Copyright Statement

No part of this publication may be reproduced in any form by any means without the prior written permission.
Regardless of any direct acknowledgement elsewhere in the body of this document, WAVLINK hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and other related documents are the property of their respective holders.

Disclaimer

Information in this document is subject to change without notice. The manufacturer does not make any representations or warranties (implied or otherwise) regarding the accuracy and completeness of this document and shall in no event be liable for any loss of profit or any commercial damage, including but not limited to special, incidental, consequential or other damage.

WEEE Directive & Product Disposal

At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

Basic Info

In the Box

1 × AX1800M USB3.0 Wireless Adapter
1 × USB3.0 Dock
1 × Quick Start Guide
1 × Driver Link Card

System Requirements

- At least one USB3.0 port
- Windows 10/11

Connection Diagram

Connect the adapter with your device via the involved USB 3.0 cable or directly insert the adapter to an open USB port, we recommend you to insert the adapter into the USB3.0 port directly.





LED Description

LED	Description
Blink in blue	Has connected/is connecting to the WI-FI
Off	Disconnected to the Wi-Fi

Driver Installation

NOTE: Please download the driver from our official website if your computer system requires.
Step 1: Find the Wireless LAN Driver Zip.
Step 2: Click to launch the execution file "**Setup.exe**", then do as per the on-screen instructions.



Step 3: After the program was automatically installed, please select "**Yes, I want to restart my computer now**", and then click on "**Finish**".



Wi-Fi Configuration

Step 1: When the computer turned on, insert the wireless card into an open USB port.
Step 2: Left-click network icon in the task bar to turn on the new WiFi.
Step 3. Select the Wi-Fi SSID you want to connect to and enter the Wi-Fi password. After successful connection, the LED would be blue and blink quickly.



Windows 10



Windows 7

NOTE:
Firstly you need to find the right WLAN name of your new wireless LAN card, then you can set it up if necessary, you can change the name in "**Network Connections**".

Verifying Installation

If your adapter is not functioning then probably the drivers are missing or the wrong drivers have been installed.

Step 1: Plug in the USB adapter.
Step 2: Right-click the computer icon>select "**Manage**" > double-click "**Device Manager**" >go to "**Network adapters**" to ensure if the right driver is installed.

Official website: www.wavlink.com
Technical support: support@wavlink.com

名称：WN690X1-B说明书WAVLINK-E1	
成品尺寸：70x100mm	页数/展开尺寸：4页/70x100mm
材质工艺： 105克铜版纸 正反印刷	
修改时间：2019.1.24	
备注：	
修改记录：	