



QUICK START GUIDE

AC1900 Wireless Dual Band USB3.0 Adapter



www.wavlink.com/en_us/WL-WN693A5
Scan the QR code or load the link for Quick Start Guide and Driver downloading

WL-WN693A5

WAVLINK (@WavlinkOfficial)
WAVLINK SUPPORT (@WavlinkTechSupport)

Safety Instructions
Keep this quick start guide for future reference.
Keep this equipment away from humidity.
If any of the following situation arises, get the device checked by a service technician.
• The equipment has been exposed to moisture.
• The equipment has been dropped and damaged.
• The equipment has obvious sign of breakage.
• The equipment has not been working well or you cannot get it work according to quick start guide.

Copyright Statement
No part of this publication may be reproduced in any form by any means without the prior written permission.
Regardless of any direct acknowledgement elsewhere in the body of this document, WAVLINK hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and other related documents are the property of their respective holders.

Disclaimer
Information in this document is subject to change without notice. The manufacturer does not make any representations or warranties (implied or otherwise) regarding the accuracy and completeness of this document and shall in no event be liable for any loss of profit or any commercial damage, including but not limited to special, incidental, consequential or other damage.

WEEE Directive & Product Disposal
At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

Basic Info


In the Box
1 x AC1900 Wireless Dual Band USB3.0 Adapter
1 x USB3.0 Cable
1 x Quick Start Guide
1 x CD-shaped Card for Driver Download Link

System Requirement
Microsoft Windows
Mac OS X
Notice: Soft AP function supports Windows 7/8/10, not available in Mac OS

LED Description

OFF	No power or not installed driver
Blink Fast	Connected to the PC and driver installed, searching for Wi-Fi signal
Blink Slowly	Connected to the PC and driver installed, disconnected from Wi-Fi signal
Solid On	Connected to Wi-Fi

Connection Diagram:



- 1 -

Internal Magnet

The adapter can be absorbed on the case panel for its internal magnet.



Driver Installation

Driver software installation may be required. Please download the driver from our official website if your computer system requires.

For Microsoft Windows 7:

Step 1: Find the Wireless LAN Driver Zip "Install.pkg".
Step 2: Click to launch the executive file "Setup.exe", then do as per the on-screen instructions.

- 2 -

EAP	File folder
BHV	File folder
Release notes	File folder
RTWLANU_Driver	File folder
Autorun.inf	1 KB
Install.bat	1 KB
logo.bmp	11.7 KB
Setup.exe	11.0 MB
setup.ini	1 KB
Uninstall.bat	1 KB
Uninstall.ini	1 KB

For Mac OS:

Step 1: Find the Wireless LAN Driver Zip "Install.pkg", then do as per the on-screen
Step 2: Click to launch the executive file instructions.

Install.pkg
Release_RTWlanU_MacOSX.txt
Uninstall.pkg
Utility_Release.txt

Step 3: Restart your computer as the system suggests.

- 3 -

Wi-Fi Connection

For Microsoft Windows

Step 1: Please plug in the USB wireless card. If the LED starts to flash slowly, you can set up the Wi-Fi.
Step 2: Right-click network icon in the task bar to turn on the new Wi-Fi.
Step 3: Select the Wi-Fi SSID you want to connect to and enter the wifi password.
After successful connection, the LED would blink quickly.



Windows 7



Windows 10


NOTE:

Firstly you need to find the right WLAN name of your new wireless LAN card then you can set it up if necessary, you can change the name in "Network Connections".

- 4 -

For Mac OS

Step 1: Please plug in the USB wireless card. If the LED starts to flash, you can set up the wifi.
Step 2: A USB Wi-Fi icon would appear at the top. Click it to open and select the Wi-Fi SSID you want to connect to.
After successful Wi-Fi connection, the USB Wi-Fi icon would turn into a green signal bar.




NOTE: Open a browser and test the connection.

- 5 -

AP Mode on Windows 7


Step 1: Click the Realtek icon or the green signal bar in the task bar to launch the utility.

Step 2: Go to "Mode(M)" on the menu and then click "Access Point" to switch.



Step 3: Click "Config" under "General" panel to create a new Wi-Fi in your computer.

- 6 -



NOTE: Please change the SSID and set the authentication for your convenience and network security.
Don't check the **Disable Adapter** box.




Step 4: After successful configuration, the green bar would turn into a Wi-Fi icon. Then you can connect your laptop, mobile and other wireless devices to the Wi-Fi.

NOTE: Don't disable your local network connection. Otherwise there is no Wi-Fi Hotspot in computer.

- 7 -

WPS One-key Connection

Press and hold the WPS Buttons of host router and adapter for 6 seconds.




Verifying Installation

If your adapter is not functioning then probably the drivers are missing or the wrong drivers have been installed.

Windows 7

Plug in the USB adapter.
Right-click the Computer icon > select Manage > double-click Device Manager > go to Network adapters to see if the right driver is installed.

- 8 -



Mac OS

Plug in the USB adapter.
Right-click the Apple icon > select About this Mac > click System Report > go to USB > click USB Device Tree to see if the right driver is installed.



- 9 -



Thank you for purchasing WAVLINK product!

Official website: www.wavlink.com
Technical support: support@wavlink.com

名称: WN693A5说明书WAVLINK-E2

成品尺寸: 90x90mm

展开: 540x90mm

材质工艺: 105g铜板+4C正反双面印刷+风琴折

修改时间:

备注: